

Polaroid  
**i-zone**

Instant Pocket Camera



## Load Film

Use Polaroid I-Zone instant pocket films.

Save this sheet for reference


**1**

Press button.




**2**

Load film.



**3**

Close door.  
Make sure it's closed.



**4**

Pull tab straight,  
firmly, and quickly.  
Do not stop.



## Take picture

**5**

Select



2-8 ft  
(.6 m - 2.4 m)

Indoors



2 ft - ∞  
(.6 m - ∞)

Outdoor: Sunny



2 ft - ∞  
(.6 m - ∞)

Outdoor: Cloudy


**6**

Wait. Ready  
light glows.



**7**

Aim. Best pictures from  
2-8 ft. (.6-2.4 m).



**8**

Press the button.



**9**

Shade from bright sun  
and pull tab straight,  
firmly, and quickly. Do  
not stop.



**10**

Have Fun! DO NOT CUT INTO  
PHOTOS. To prevent exposure to  
caustic paste, cut where indicated.

